

GRANDVIEW®
GRANDVIEW REPRODUCING GENUINE COLORS

**Instruction Manual
for Table-Top Screen**

U-WORK

GRANDVIEW®
GRANDVIEW REPRODUCING GENUINE COLORS



Grandview Crystal Screen Canada Ltd.

#11-3751 North Fraser Way,
Marine Way Business Centre,
Burnaby, BC, Canada V5J 5G4
Tel: 1-604-412-9777 Fax: 1-604-412-9796
Website: www.grandviewscreen.ca

Guangzhou Grandview Crystal Screen Co., Ltd.

P.O. 511400 Federal Ind. Zone No. 363, Yushan West Road,
Shiqiao, Panyu District, Guangzhou, Guangdong, China
Tel: +8620-8489-9499 Fax: +8620-8480-3343
Website: www.grandviewscreen.com




Model: PT-Bxx

Thank you for purchasing a Grandview projection screen.
Before use, please read instructions carefully. After installation, keep instructions for future reference.

Description

Illustration



Part name

①	Lock / Unlock	⑨	Right Upper Cap
②	Leg Support	⑩	Right End Cap
③	Casing	⑪	Support Handle
④	Left End Cap	⑫	Upper Support Arm
⑤	Black Border	⑬	Upper Joint
⑥	Viewing Area	⑭	Lower Joint
⑦	Left Upper Cap	⑮	Lower Support Arm
⑧	Top Cover/Rod	⑯	

Contents

- Bag (1 pc)
- Installation Manual (1 pc)
- Warranty Card (1 pc)





Note

The surface of the screen is designed for optimal performance when properly maintained. Any damage to the surface will affect image quality.

Caution

- Please do not shake the screen.
- Please do not use any chemicals or cleaning agents to clean the screen. The chemical agents and corrosive elements may cause unevenness on the projection coating.



- Please do not mark the screen surface.




- Please do not pull or retract the screen with too much force.




Maintenance

- If the screen needs to be cleaned, please use a dry-cloth or soft duster and clean gently. If more cleaning is needed, use a soft-cloth with water.
- For dust build-up, a soft-duster or brush can be gently used.



Location

- Please keep the screen away from direct sunlight, dust and moisture. Avoid using in strong winds.



Caution


- Please contact your local dealer for repairs and issues. Please contact us if you have any questions. Avoid taking apart the screen yourself.



Specifications

Format	Model	Specification (In)	Viewing area		Screen dimension		Net weight (kg)
			W (mm)	H (mm)	L (mm)	A (mm)	
4:3	PT-BT-32	32	650	488	742	566	1.13
4:3	PT-BT-40	40	813	610	905	688	1.46

Note: Sizes and specifications are subject to change at any time. Refer to actual product for exact measurements. The tolerance for L is ± 5 mm.



Using the Screen

1. Position the screen facing the projector on a level surface. Once the position is determined, extend the leg support out (figures 1, 2 and 3).




Figure 1




Figure 3




Figure 2

2. As illustrated in figure 2-1, hold using your fingers to unlock the screen. When unlocked, slowly pull the screen up to the desired height (figure 2-2).




Figure 2-1




Figure 2-2

Closing the Screen

1. As illustrated in figures 3-1, 3-2 and 3-3, turn in the leg support when the screen is not in use.




Figure 3-1




Figure 3-2




Figure 3-3

2. As illustrated in figure 4-1, hold using your fingers to unlock the screen. When unlocked, slowly push the screen down and ensure the cover is locked into the casing (figure 4-2).




Figure 4-1




Figure 4-2

Note: When using and retracting the screen, please watch your fingers to avoid injury (figure 4-3).




Figure 4-3




Figure 4-3